



2109

- GB** Installation Guide
- D** Einbauanleitung
- F** Guide d'installation
- I** Guida all'installazione
- E** Guía de instalación
- S** Installationsanvisningar
- PL** Instrukcja montażu



2109



2109	mm							
	SL	TR	A	B	C	D	E	F
HAZ2109-0030-2	300	205	96	—	—	—	242	215.9
HAZ2109-0035-2	350	260	128	—	—	—	292	215.9
HAZ2109-0040-2	400	281	128	—	—	—	342	215.9
HAZ2109-0045-2	450	331	128	224	—	—	392	215.9
HAZ2109-0050-2	500	376	128	224	—	—	442	292.1
HAZ2109-0055-2	550	415	128	224	320	—	492	292.1

