



# 3301-60

- GB** Installation Guide
- D** Installationsanleitung
- F** Guide d'installation
- I** Guida all'installazione
- E** Guía de instalación
- PL** Instrukcja montażu



3301-60	mm							
	SL	TR	A	B	C	D	E	F
HAZ3301-6030	300	325.0	-	-	224	-	-	190
HAZ3301-6035	350	374.2	-	-	224	256	-	240
HAZ3301-6040	400	436.1	160	192	320	-	-	290
HAZ3301-6045	450	498.0	160	192	320	352	-	340
HAZ3301-6050	500	547.2	192	224	416	448	-	390
HAZ3301-6055	550	596.4	-	224	448	480	250	440
HAZ3301-6060	600	658.3	256	288	480	512	250	490
HAZ3301-6065	650	707.5	256	288	544	576	250	540
HAZ3301-6070	700	769.4	288	416	576	608	250	590

