



- GB** Installation Guide
- D** Einbauanleitung
- F** Guide d'installation
- I** Guida all'installazione
- E** Guía de instalación
- S** Installationsanvisningar
- PL** Instrukcja montażu



 68 kg



3301	mm							
	SL	TR	A	B	C	D	E	F
HAZ3301-0012-2	305	330	-	162.1	222.2	235.0	260.3	209.5
HAZ3301-0014-2	356	381	-	212.8	273.0	285.7	311.1	260.3
HAZ3301-0016-2	406	432	-	263.6	323.8	336.5	361.9	311.1
HAZ3301-0018-2	457	483	212.8	314.4	374.6	387.3	412.7	361.9
HAZ3301-0020-2	508	533	238.2	365.2	425.4	438.1	463.5	412.7
HAZ3301-0022-2	559	584	263.6	416.0	476.2	488.9	514.3	463.5
HAZ3301-0024-2	610	635	289.0	466.8	527.0	539.7	565.1	514.3
HAZ3301-0026-2	660	686	314.4	517.6	577.8	590.5	615.9	565.1
HAZ3301-0028-2	711	737	339.8	568.4	628.6	641.3	666.7	615.9

